

**MULTISPAN MULTI FUNCTION METER MFM - 13**



**TECHNICAL SPECIFICATION**

**PARAMETER SPECIFICATION**

Input Signal	3Ø 3 Wire / 3Ø 4Wire / 1Ø 2Wire
CT Primary	up to 6000A (Programmable)
CT Secondary	5 Amp/1 Amp selectable
PT Primary	100V to 520kV (Programmable)
PT Secondary	100V to 520V (L-L) (Programmable)
PF Avg. & Per Phase	0.100 - 1.000
Frequency (Hz)	45.00 - 60.00 Hz
Load hours	9999.59 Hrs/Min.
No load hours	9999.59 Hrs/Min.
RPM	3600 RPM @ 60 Hz & 2 pole

**POWER**

KW Total	0.000 - 9999 MW
kW Per Phase	0.000 - 9999 MW
kVA Total	0.000 - 9999 MVA
kVA Per Phase	0.000 - 9999 MVA
kVAr Total	0.000 - 9999 MVAR
kVAr Per Phase	0.000 - 9999 MVAR

**ENERGY**

kWH Total	000.000 - 999999999.999 kWh
kVAh Total	000.000 - 999999999.999 kVAh
kVArh Total	000.000 - 999999999.999 kVArh

**DISPLAY & KEY :**

Display	4 Digit, 3 Line 0.57" RED
Key	SET/ENT, VAF, P/E, INC, DEC

**DIMENSION :**

Size	96 (H) x 96 (W) x 54 (D) mm
Panel Cutout	92 (H) x 92 (W) mm

**AUXILIARY SUPPLY :**

Supply voltage	12V - 60V DC
----------------	--------------


**ACCURACY:**

Class 0.5 (Standard)	
----------------------	--


**ENVIRONMENT CONDITION:**

Operating Temp.	0°C to 55°C
Relative Humidity	UP to 95% RH (non-condensing)
Protection Level (AS Per Request)	IP-65 (Front side) As per IS/IEC 60529 : 2001

**MECHANICAL INSTALLATION**



**TERMINAL CONNECTION**



**KEY OPERATION**

FUNCTION	PRESS KEY
<b>OPERATOR MODE</b>	
To view VAF Pages	[VAF]
To view Power & Energy Pages	[P/E]
To scroll & hold pages	Press [Up] + [Down] For 5Sec
<b>PARAMETER SETTING MODE</b>	
To Set Parameter Value	Press [SET/ENT] For 5 Sec
To Increment parameter value	[Up]
To Decrement parameter value	[Down]
To Exit from parameter setting	[SET/ENT]

Resolution	
PT Ratio x CT Ratio	Pulse/Kwh
<15	0.01Kwh
<150	0.1Kwh
<1500	1Kwh
<15000	10Kwh
<150000	100Kwh
≥150000	1000Kwh

**INSTALLATION GUIDELINES**

1. This equipment, being built-in-type, normally becomes a part of main control panel and in such case the terminals do not remain accessible to the end user after installation and internal wiring.
2. Do not allow pieces of metal, wire clippings, or fine metallic fillings from installation to enter the product or else it may lead to a safety hazard that may in turn endanger life or cause electrical shock to the operator.
3. Circuit breaker or mains switch must be installed between power source and supply terminal to facilitate power 'ON' or 'OFF' function. However this mains switch or circuit breaker must be installed at convenient place normally accessible to the operator.
4. Use and store the instrument within the specified ambient temperature and humidity ranges as mentioned in this manual.

**MECHANICAL INSTALLATION GUIDELINES**

1. Prepare the panel cutout with proper dimensions as shown above.
2. Fit the unit into the panel with the help of clamp given.
3. The equipment in its installed state must not come in close proximity to any heating source, caustic vapors, oils steam, or other unwanted process byproducts.
4. Use the specified size of crimp terminal (M3.5 screws) to wire the terminal block. Tightening the screws on the terminal block using the tightening torque of the range of 1.2 N.m.
5. Do not connect anything to unused terminals.

**MAINTENANCE**

1. The equipment should be cleaned regularly to avoid blockage of ventilating parts.
2. Clean the equipment with a clean soft cloth. Do not use isopropyl alcohol or any other cleaning agent.
3. Fusible resistor must not be replaced by operator.

**SAFETY PRECAUTION**

All safety related codifications, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If all the equipment is not handled in a manner specified by the manufacturer, it might impair the protection provided by the equipment.

Read complete instructions prior to installation and operation of the unit.

**WARNING :** Risk of electric shock.

**WARNING GUIDELINES**


**WARNING :** Risk of electric shock.

1. To prevent the risk of electric shock, power supply to the equipment must be kept OFF while doing the wiring arrangement. Do not touch the terminals while power is being supplied.
2. To reduce electro magnetic interference, use wire with adequate rating and twists of the same of equal size shall be made with shortest connection.
3. Cable used for connection to power source, must have a cross section of 1mm or greater. These wires should have insulations capacity made of at least 1.5kV.
4. A better anti-noise effect can be expected by using standard power supply cable for the instrument.

**PARAMETER SETTING**

Long Press [SET/ENT] key

Enter Password 10



**BASIC MODE PAGES**

**VAF Pages :**

Press [VAF] key to change page

<p><b>1) Voltage L-N</b></p>	<p><b>6) AVG V(L-L)-A-F</b></p>
<p><b>2) Voltage L-L</b></p>	<p><b>7) PF L1L2L3</b></p>
<p><b>3) Current</b></p>	<p><b>8) System PF</b></p>
<p><b>4) System Frequency</b></p>	<p><b>9) AVG V(L-N)-A-PF</b></p>
<p><b>5) AVG V(L-N)-A-F</b></p>	<p><b>10) AVG V(L-L)-A-PF</b></p>

Note : In 3P-3W Page 2,3,4,6,8,10 will display

**POWER & ENERGY Pages :**

Press [P/E] key to change page

<p><b>1) kW PER PHASE</b></p>	<p><b>5) kWh Total</b></p>
<p><b>2) kVA PER PHASE</b></p>	<p><b>6) kvah Total</b></p>
<p><b>3) kvar PER PHASE</b></p>	<p><b>7) kvarh Total</b></p>
<p><b>4) TOTAL kVA,kvar,kW</b></p>	<p>Note : In 3P-3W Page 4,5,6,7 will display</p>

**1Phase 2 wire Pages**

<p><b>1) V(L-N)-A-F</b></p>	<p><b>2) V(L-N)-A-PF</b></p>	<p><b>3) TOTAL kVA,kvar,kW</b></p>
<p><b>4) kWh Total</b></p>	<p><b>5) kvah Total</b></p>	<p><b>6) kvarh Total</b></p>

## ADVANCE MODE PAGES

### VAF Pages :

Press **VAF** key to change page

#### 1) Voltage L-N

$V_{L-N}$   
L<sub>1</sub> 2419  
L<sub>2</sub> 2384  
L<sub>3</sub> 2405

#### 2) Voltage L-L

$V_{L-L}$   
L<sub>1,2</sub> 4185  
L<sub>2,3</sub> 4126  
L<sub>3,1</sub> 4162

#### 3) Current

$I$   
L<sub>1</sub> 4999  
L<sub>2</sub> 5001  
L<sub>3</sub> 4890

#### 4) System Frequency

FrE9  
5000 Hz

#### 5) Line 1 V(L-N)-A-F

$V_{L-N}$   
L<sub>1</sub> 2306  
L<sub>2</sub> 5963  
L<sub>3</sub> 5065 Hz

#### 6) Line 2 V(L-N)-A-F

$V_{L-N}$   
L<sub>2</sub> 2346  
L<sub>3</sub> 4967  
5035 Hz

#### 7) Line 3 V(L-N)-A-F

$V_{L-N}$   
L<sub>3</sub> 2406  
L<sub>1</sub> 4732  
L<sub>2</sub> 4964 Hz

#### 8) AVG V(L-N)-A-F

$V_{L-N}$   
AVG 2402  
L<sub>1</sub> 4963  
L<sub>2</sub> 5005 Hz

#### 9) Line 12 V(L-L)-A-F

$V_{L-L}$   
L<sub>1,2</sub> 4325  
L<sub>2,3</sub> 5746  
L<sub>3,1</sub> 5045 Hz

#### 10) Line 23 V(L-L)-A-F

$V_{L-L}$   
L<sub>2,3</sub> 4356  
L<sub>1,2</sub> 4962  
L<sub>3,1</sub> 5045 Hz

#### 11) Line 31 V(L-L)-A-F

$V_{L-L}$   
L<sub>3,1</sub> 4299  
L<sub>1,2</sub> 3657  
L<sub>2,3</sub> 5045 Hz

#### 12) AVG V(L-L)-A-F

$V_{L-L}$   
AVG 4202  
L<sub>1,2</sub> 4965  
L<sub>2,3</sub> 5045 Hz

#### 13) PF L1 L2 L3

$PF$   
L<sub>1</sub> 0982  
L<sub>2</sub> 0983  
L<sub>3</sub> 0981

#### 14) System PF

$PF$   
Σ 5467  
0982

#### 15) Line 1 V(LN)-A-PF

$V_{L-N}$   
L<sub>1</sub> 2306  
L<sub>2</sub> 5963  
L<sub>3</sub> 0951  $PF$

#### 16) Line 2 V(LN)-A-PF

$V_{L-N}$   
L<sub>2</sub> 2346  
L<sub>3</sub> 4967  
0982  $PF$

#### 17) Line 3 V(LN)-A-PF

$V_{L-N}$   
L<sub>3</sub> 2406  
L<sub>1</sub> 4732  
L<sub>2</sub> 0964  $PF$

#### 18) AVG V(LN)-A-PF

$V_{L-N}$   
AVG 2402  
L<sub>1</sub> 4963  
L<sub>2</sub> 0983  $PF$

#### 19) Line 12 V(LL)-A-PF

$V_{L-L}$   
L<sub>1,2</sub> 4325  
L<sub>2,3</sub> 5746  
0987  $PF$

#### 20) Line 23 V(LL)-A-PF

$V_{L-L}$   
L<sub>2,3</sub> 4356  
L<sub>1,2</sub> 4962  
0952  $PF$

#### 21) Line 31 V(LL)-A-PF

$V_{L-L}$   
L<sub>3,1</sub> 4299  
L<sub>1,2</sub> 3657  
L<sub>2,3</sub> 0961  $PF$

#### 22) AVG V(LL)-A-PF

$V_{L-L}$   
AVG 4202  
L<sub>1,2</sub> 4963  
L<sub>2,3</sub> 0983  $PF$

### POWER & ENERGY Pages :

Press **P/E** key to change page

#### 1) kW PER PHASE

$kW$   
L<sub>1</sub> 1184  
L<sub>2</sub> 1168  
L<sub>3</sub> 1152

#### 2) kVA PER PHASE

$kVA$   
L<sub>1</sub> 1209  
L<sub>2</sub> 1192  
L<sub>3</sub> 1176

#### 3) kvar PER PHASE

$kVar$   
L<sub>1</sub> 0296  
L<sub>2</sub> 0239  
L<sub>3</sub> 0236

#### 4) Line 1 kVA,kvar,kW

$kVA$   
L<sub>1</sub> 1209  
 $kVar$   
0296  
 $kW$   
1184

#### 5) Line 2 kVA,kvar,kW

$kVA$   
L<sub>2</sub> 1192  
 $kVar$   
0239  
 $kW$   
1168

#### 6) Line 3 kVA,kvar,kW

$kVA$   
L<sub>3</sub> 1176  
 $kVar$   
0236  
 $kW$   
1152

#### 7) TOTAL kVA,kvar,kW

$kVA$   
Σ 3577  
 $kVar$   
0257  
 $kW$   
Σ 3504

#### 8) kWh Total

$kWh$   
1549  
0935

#### 9) kvah Total

$kVAh$   
1908  
2034

#### 10) kvarh Total

$kVarh$   
8452  
0.176

Note :  
In 3P-3W Page  
7,8,9,10 will display

Press **▲** OR **▼** to View Load Hour & RPM

#### 1) Load Hour

LHr5  
213  
53 M

#### 2) No Load Hour

nHr5  
150  
01 M

#### 3) RPM

rPn  
3000

### 1Phase 2 wire Pages

#### VAF Pages :

##### 1) V(L-N)-A-F

$V_{L-N}$   
2306  
506  
5006 Hz

##### 2) V(L-N)-A-PF

$V_{L-N}$   
2306  
506  
0982  $PF$

#### Power & Energy Pages :

##### 1) TOTAL kVA,kvar,kW

$kVA$   
Σ 3577  
 $kVar$   
0257  
 $kW$   
Σ 3504

##### 3) kvah Total

$kVAh$   
1908  
2034

##### 2) kWh Total

$kWh$   
1549  
0935

##### 4) kvarh Total

$kVarh$   
8452  
0.176

## LOAD HOUR & RPM

Enter Password 25  
PASS 25  
LHr5 Load Hour  
Enb Enable / Disable  
LOAD PERC Load Hour Percentage (5 to 50%)  
40  
rPn RPM  
Enb Enable / Disable  
POLE Pole  
4 (1 to 128)  
PLSE ON Pulse ON Time (10 to 500ms)  
100  
PLSE Mode Auto / Manual  
IF Auto AUTO  
PLSE OUT Pulse Out  
0001  
0.01, 0.1, 1, 10, 100, 1000  
Press **PRG** key to save & exit from parameter setting

## RESET SETTINGS

Enter Password 15  
PASS 15  
PRG rEst ALL (Yes/No)  
YES  
PRG rEst kWh (Yes/No)  
YES  
PRG rEst kVAh (Yes/No)  
YES  
PRG rEst kVArh (Yes/No)  
YES  
PRG rEst Load Hour (Yes/No)  
YES  
PRG rEst No Load Hour (Yes/No)  
YES  
Press **PRG** key to save & exit from parameter setting

Note : In 3P-3W Page 2,3,4,9,10,11,12,14,  
22 will display